



Installation Instructions

Forward Horn

Made in USA



WARNING!

Failure to install or use this product according to manufacturers recommendations could result in property damage, serious injury, and/or death.



Do not install and/or operate this safety product unless you have read and understand the safety information contained on this sheet.

General Information:

This [forward horn](#) is designed to project an audible warning sound in hazardous areas. To realize this product's full value, it must be installed in conformance with the instructions provided in this guide. Peoples lives depend on the proper installation of this product and it is necessary for you to read, understand and follow these instructions.

Forward horns are intended for commercial use. Proper installation of a forward horn requires a good understanding of vehicle electrical systems and procedures, along with proficiency in the installation and use of safety warning equipment.

This horn sound may be used to warn that a vehicle is going to move forward, is coming to a corner, etc. Place the horn so it will operate properly under adverse conditions. The location must provide protection from impact and poor weather conditions while allowing unobstructed sound projection to the target hazard area.


Mounting:

Mount the horn facing forward, avoiding any obstruction to the sound output face. DO NOT mount the horn with the face oriented directly upward or directly downward. The horn should be mounted approximately four feet above ground level in a protected location to avoid collision damage. When installing the forward horn, be sure to verify that both sides of the mounting surface are clear of anything that could be damaged during installation. Keep the horn clean and check for proper operation daily before use.

Connections:

Connect the horn to power using fuse and switch as shown in the illustration below. For proper operation please observe correct polarity when hooking up wires. The horn is polarity protected so no damage will occur if wires are accidentally connected backwards. Use 18 gauge wire (minimum). The ground connection on grounded electrical systems MUST be attached to a solid metal body or chassis part that will provide a dependable ground path as long as the device is in use, or directly to the battery negative terminal. Route wire in a protected manner in accordance with vehicle manufacturer recommendations. **DO NOT install the horn or its wiring in proximity to ignition wires. Failure to observe these conditions may have an adverse effect on the horn's performance.** Switches that can be used to activate the horn are available.

IMPORTANT! This unit is a safety device, and it must be connected to its own separate, fused power point to assure its continued operation should any other electrical accessory fail.



NOTE: DO NOT WIRE UP THE HORN FOR BACK-UP WARNING APPLICATIONS.

Vehicle Operations:

As the operator of a vehicle, you should always know when the horn is sounding and when it is not sounding. Should the horn become inoperative, discontinue vehicle operation and notify your supervisor or team leader. Operating a vehicle with a horn that is not functioning properly could endanger the lives and/or property of those who depend on the horn signal for safety.

Maintenance:

Preventative maintenance procedures must specify a safety system inspection. This check should include a thorough examination of the electrical connections and the sound opening of the horn. The sound opening must be kept clear of dust, mud, or any other foreign material that may prevent the horn from sounding properly. Should this inspection reveal a horn that is not functioning properly, do not operate the vehicle, and immediately notify your supervisor or maintenance personnel.

Manufacturer Limited Warranty and Limitation of Liability:

Manufacturer warrants that on the date of purchase this product will conform to Manufacturer's specifications for this product (which are available from the Manufacturer upon request), and Manufacturer further warrants that this product is free from defects in materials and workmanship. This Limited Warranty extends for twenty-four (24) months from the date of purchase. Other warranties may apply, call Manufacturer for details. Manufacturer will, at its discretion, repair or replace any product found by the Manufacturer to be defective and subject to this Limited Warranty.

DAMAGE TO PARTS OR PRODUCTS RESULTING FROM TAMPERING, ACCIDENT, ABUSE, MISUSE, NEGLIGENCE, UNAPPROVED MODIFICATIONS, FIRE OR OTHER HAZARD; IMPROPER INSTALLATION OR OPERATION; OR NOT BEING MAINTAINED IN ACCORDANCE WITH THE MAINTANANCE PROCEDURES SET FORTH IN MANUFACTURER'S INSTALLATION AND OPERATING INSTRUCTIONS VOIDS THIS LIMITED WARRANTY.

ORAL STATEMENTS OR REPRESENTATIONS ABOUT THE PRODUCT WHICH MAY HAVE BEEN MADE BY SALESPEOPLE, DEALERS, AGENTS OR OTHER MANUFACTURER'S REPRESENTATIVES DO NOT CONSTITUTE WARRANTIES. THIS LIMITED WARRANTY MAY NOT BE AMENDED, MODIFIED, OR ENLARGED EXCEPT BY A WRITTEN AGREEMENT SIGNED BY AN AUTHORIZED OFFICIAL OF MANUFACTURER WHICH EXPRESSLY REFERS TO THIS LIMITED WARRANTY.

Exclusion of Other Warranties:

MANUFACTURER MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED. THE IMPLIED WARRANTIES FOR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY EXCLUDED AND SHALL NOT APPLY TO THE PRODUCT. BUYER'S SOLE AND EXCLUSIVE REMEDY IN CONTRACT, TORT, OR UNDER ANY OTHER THEORY AGAINST MANUFACTURER REGARDING THE PRODUCT AND ITS USE SHALL BE THE REPLACEMENT OR REPAIR OF THE PRODUCT AS DESCRIBED ABOVE.

Limitation of Liability:

IN THE EVENT OF LIABILITY FOR DAMAGES ARISING OUT OF THIS LIMITED WARRANTY OR ANY OTHER CLAIM RELATED TO THE MANUFACTURER'S PRODUCTS, MANUFACTURER'S LIABILITY FOR DAMAGES SHALL BE LIMITED TO THE AMOUNT PAID FOR THE PRODUCT AT THE TIME OF THE ORIGINAL PURCHASE. IN NO EVENT SHALL MANUFACTURER BE LIABLE FOR LOST PROFITS, THE COST OF SUBSTITUTE EQUIPMENT OR LABOR, PROPERTY DAMAGE, OR OTHER SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES BASED UPON ANY CLAIM FOR BREACH OF CONTRACT, IMPROPER INSTALLATION, NEGLIGENCE, OR OTHER CLAIM, EVEN IF MANUFACTURER OR A MANUFACTURER'S REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. MANUFACTURER SHALL HAVE NO FURTHER OBLIGATION OR LIABILITY WITH RESPECT TO THE PRODUCT OR ITS SALE, OPERATION AND USE, AND MANUFACTURER NEITHER ASSUMES NOR AUTHORIZES THE ASSUMPTION OF ANY OTHER OBLIGATION OR LIABILITY IN CONNECTION WITH SUCH PRODUCT.

This Limited Warranty defines specific legal rights. You may have other legal rights which vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages.
