# CDR6221

QUICK START GUIDE

DVD Multimedia Receiver with Bluetooth
featuring a 6.2" digital touch screen TFT

This Quick Start Guide gives you the basics to
start using your CDR6221. Please visit
www.jensenmobile.com
to download a complete owner's manual or call customer
service at 1-888-921-4088 (Monday-Friday, 9AM-5PM EST).

Bluetooth

JENSEN®

Installation

UNIT

TRIM PLATE

TYPICAL FRONT-LOAD DIN MOUNTING METHOD

Wiring Diagram - Inputs/Outputs

10A

FUSE
If fused,
replace with same
specification value
10A

FR OUT FL OUT V OUT SUB OUT
RR OUT RL OUT CAM IN SUB OUT ANT

Radio Antenna

EXTERNAL MIC INPUT

20PIN

FRONT LEFT SPEAKER	WHITE
	WHITE / BLACK
FRONT RIGHT SPEAKER	GRAY
	GRAY / BLACK
REAR LEFT SPEAKER	GREEN
	GREEN/BLACK
REAR RIGHT SPEAKER	VIOLET
	VIOLET / BLACK

PINK	PARKING BRAKE (-)
VIOLET/WHITE	REVERSE (+)
GRAY (Red Cap)	SWC - 3.5mm JACK
	Steering Wheel Control (SWC) Input (Compatible with most SWC interfaces)
BLUE/WHITE	REMOTE TURN-ON (+)
BLUE	POWER, ANTENNA (+)
ORANGE	ILLUMINATION (+)
RED	ACC (B+)
BLACK	GROUND (P-)
YELLOW	BATTERY (B+)

Control Locations

1. MIC
2. miroSD card slot
3. Eject-Press to eject disc
4. Reset
5. Press- Mode Change
   Press and hold -- Voice Activation
6. Tune/Track Up
7. Volume/Power/Mute
8. Tune/Track Down
9. USB port
10. AUX

Main Menu

Press the Top Left Source icon to enter Main Source Menu
In the Menu mode, press the desired icon to enter the desired mode:

1. Radio Direct
2. Media Player Last Source
3. BT Handsfree Direct
4. DISC Direct
5. USB Direct
6. microSD Card Direct
7. BT Streaming Direct
8. AUX In Direct
9. Rear/Front Camera
10. Main System Setup Menu

## Tuner Operation

Select the Tuner icon from the Main Menu screen

1. Current Mode Icon / Main Source Menu
2. Tuner Presets - Press and hold to set
3. AM Direct
4. FM Direct
5. Bluetooth Handsfree Direct
6. Stereo / Mono
7. Previous Station - Press and hold to
   Manual Tune
8. AS/PS - Auto Scan / Preset Scan
9. Direct Station Entry
10. Station Number
11. Station Search
12. Next Station - Press and hold to Manual Tune
13. EQ Settings
14. Quick BAND Select - FM 1-2-3 | AM 1-2

CD/DVD Operation

Insert a CD/DVD in the disc slot for playback

1. Direct File Entry
2. EQ Setting
3. Repeat
4. Random
5. Next Page

Media Player Operation

USB/microSD/BT Music operation will
work the same way.

1. Current Mode / Main Source Menu
2. BT Streaming Music Direct
3. USB Media Direct
4. microSD Direct
5. Bluetooth Handsfree Direct
6. Shuffle On / Off
7. Repeat 1 | All | Off
8. Direct File Entry
9. File List
10. EQ Settings
11. Track Down
12. Play/Pause
13. Track Up
14. Track Time / Status Bar
15. File Playing - ID3 Metadata
16. Track Counter of Folder

BT Media Player

Audio Operation

Press EQ icon in each Source to select EQ settings

1. Main System Volume
2. EQ Settings
3. EQ On/Off
4. Loudness On/Off
5. EQ Reset
6. Return to Source
7. EQ Presets / Custom
8. Balance / Fader

Balance/Fader Subwoofer On/Off

1. Main Volume
2. Fader Reset
3. Subwoofer ON/OFF
4. Return to Source
5. Return to EQ Controls

System Settings

1. Back to Main Menu
2. General Setup
3. Clock Settings
4. System Audio
5. Bluetooth
6. Display Adjustment
7. About - Software Version

Handfree Operation

Bluetooth Microphone

The built-in microphone is on the front of the receiver.
An external microphone is also included and is designed to mount on a visor or on a pillar
inside the vehicle.

Pairing and Connecting

Before using Bluetooth functions, you must pair your mobile phone to the CDR6221. The
device name is "JENSEN CDR6221".The Bluetooth passcode "0000".To ensure the best
reception for pairing and re-connection, please make sure the mobile phone battery is fully
charged before you begin.
• Try to perform pairing within a few minutes of the mobile phone being turned on.
• Once the unit has been paired with the mobile phone, the unit's model number,"JENSEN
CDR6221", will be displayed on the mobile phone.
• To achieve the best performance, always keep the mobile phone within 10 feet (3 meters)
of the unit.
• Always keep a clear path between the mobile phone and the unit. Never place a metal
object or any other obstacle between the mobile phone and the unit.
• Some mobile phones may have a "Power Saving Mode" option. PLEASE DO NOT use
the power saving mode with the CDR6221.
• Before accepting or making a call, make sure your mobile phone's "Bluetooth function" is
turned on.

Dialing a Number
Press keypad to dial a numbe

Making a Call
Dial number,press to connect a call

1. Current Mode / Main Source Menu
2. Dial Keypad
3. Back to Last Source
4. Bluetooth Keypad
5. Contacts - must be manually synced
6. Keypad Backspace
7. Recent Calls
8. Device Manager
9. Call Button
10. Number

Phone Book
Press [ ] to download the phone numbers or access the call history info.

Transferring Audio
Press to transfer call audio between
the headunit and mobile phone.

1. Hang Up
2. Call Transfer
3. MIC Mute
4. Return to Keypad

One-Year (or Two-Year*) Limited Warranty

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.
Namsung America Inc warrants this product to the original purchaser to be free from defects in material and
workmanship for a period of one year (or two years*) from the date of the original purchase.
Namsung America Inc agrees, at our option, during the warranty period, to repair any defect in material or
workmanship or to furnish an equal new, renewed or comparable product (whichever is deemed necessary)
in exchange without charges, subject to verification of the defect or malfunction and proof of the date of purchase.
Subsequent replacement products are warranted for the balance of the original warranty period.

Who is covered?
This warranty is extended to the original retail purchaser for products purchased from an authorized
JENSEN dealer and used in the U.S.A.

What is covered?
This warranty covers all defects in material and workmanship in this product.
The following are not covered: software, installation/removal costs, damage resulting from accident, misuse,
abuse, neglect, product modification, improper installation, incorrect line voltage, unauthorized repair or failure
to follow instructions supplied with the product, or damage occurring during return shipment of the product.
Specific license conditions and copyright notices for the software can be found via www.jensenmobile.com.

Warranty Coverage
Limited 1-year warranty when purchased from an authorized Jensen dealer.
or
*Limited 2-year warranty when purchased from and professionally installed by an authorized Jensen dealer.
(Proof of purchase and Installation required)

What to do?
1. Before you call for service, check the troubleshooting guide in your owner's manual. A slight adjustment of any
custom controls may save you a service call.
2. If you require service during the warranty period, you must carefully pack the product (preferably in the original
package) and ship it by prepaid transportation with a copy of the original receipt from the retailer to an authorized
service center.
3. Please describe your problem in writing and include your name, a return UPS shipping address (P.O. Box not
acceptable), and a daytime phone number with your shipment.
4. For more information and for the location of the nearest authorized service center please contact us by one of the
following methods:

• Call us toll-free at 1-888-921-4088
(Monday-Friday, 9:00 a.m. to 5:00 p.m. EST)

• E-mail us at cs@jensenmobile.com

Exclusion of Certain Damages: This warranty is exclusive and in lieu of any and all other warranties, expressed or
implied, including without limitation the implied warranties of merchantability and fitness for a particular purpose and
any obligation, liability, right, claim or remedy in contract or tort, whether or not arising from the company's negligence,
actual or imputed. No person or representative is authorized to assume for the company any other liability in
connection with the sale of this product. In no event shall the company be liable for indirect, incidental or consequential
damages.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference.
(2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could
void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part
15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a
residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and
used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause
harmful interference to radio or television reception, which can be determined by turning the equipment off and on,
the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.