



aFe POWER Silver Bullet

Throttle Body Spacer

Part Number: 46-34019

INSTALLATION INSTRUCTIONS

Important!

This kit includes the parts for several different installations; please verify the parts list and read all instruction steps before you begin installation.

Make	Model	Year	Engine	Make	Model	Year	Engine
Chevrolet	Silverado 1500	07-13	V6-4.3L	GMC	Sierra 1500	07-13	V6-4.3L

1. Loosen and remove air inlet tube from throttle body.
2. Loosen and remove four bolts (some models may use studs, if so, use a 4mm 6-point socket to remove the studs from the intake manifold) securing the throttle body to intake manifold.
3. Install the Silver Bullet Throttle Body Spacer (engraving side facing upward). Now slip the supplied gasket in between the spacer and throttle body assembly. Fasten the throttle body with the supplied longer bolts and washers. Tighten the bolts to 10 Nm (89 lb/in).
4. Install air inlet tube from air box assembly and the throttle body. Secure the clamps firmly.



Parts List

- 1 Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 60mm bolts
- 4 6mm flat washers

advanced FLOW engineering, inc.

Learn more about performance air intake systems we have.