



aFe POWER Silver Bullet

Throttle Body Spacer

Part Number: 46-34022


INSTALLATION INSTRUCTIONS

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make	Model	Year	Engine	Make	Model	Year	Engine
Chevrolet	Trailblazer	02-09	L6-4.2L	Isuzu	Ascender	07-09	L6-4.2L
GMC	Envoy	02-09	L6-4.2L	Oldsmobile	Bravada	07-09	L6-4.2L
Saab	9-7X	05-09	L6-4.2L	Buick	Rainer	2007	L6-4.2L

1. Loosen and remove air inlet and resonator assembly from throttle body.
2. Loosen and remove the four retaining studs/nuts.
3. Install the Silver Bullet Throttle Body Spacer between the intake manifold and throttle body assembly (engraving facing the throttle body). Now slip the supplied gasket in between the spacer and throttle body assembly. Fasten the throttle body with the supplied longer bolts and washers. Tighten the bolts to 89lb/in.
4. Install the extension brackets using the 25mm bolts and washers for the air resonator support. Bolt the air resonator to the new extension brackets.
5. Reinstall air inlet and resonator assembly.
6. Your installation is now complete.



Parts List

- 1 Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 60mm bolts
- 2 6mm x 25mm bolts
- 6 6mm washers
- 2 6mm extender brackets

advanced FLOW engineering, inc.