



Grille Installation Instruction

Part#	GR05GEE04T	Application	For 2002-2006 Jaguar Xtype
-------	------------	-------------	-----------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	2	Stainless steel	4	Washers	8	
	2	Screws	8	6-32×1.5"	5	2-Hole tabs	2	
	3	Nylon Lock Nuts	8	6-32	6	2-Hole tabs	2	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Split the OEM grille as shown.	<p>PLASTIC SUPPORT TO THE HOOD'S CAR. CHROME FRAME MIDDLE PART WITH ORIGINAL GRILL</p>
4	Cut the plastic grids on middle part. Reinstall the middle part into the chrome frame. Mesh Grille insert the frame as shown.	<p>MIDDLE PART CHROME FEAME</p>
5	Thread a screw in each nut welded to the grille. From the rear, place the tab on the screw. Now thread a nut and a washer on each screw.	
6	Make sure the insert is centered and tighten the hardware.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!