

Model # 7898

UNDERCAR KITS



Deluxe Noid Lite and GM AC Signal Test Lights Set



FEATURES:

- Economic way to check electronic fuel injection (EFI) signals
- Quickly and easily checks for systems of GM TBI, Bosch PFI Ford TBI, GM PFI, Geo TBI and GM SCPI
- To test, just disconnect the fuel injectors, plug the Noid Lite into injector wiring harness then crank the engine
- Normal voltage is indicated by flashing light which is visible from passenger compartment
- Blow molded case for easy storage and transport

Shop for other automotive tools on our website.