

banks

with Installation Instructions
Owner's Manual

**Gauge Pod
Install Manual**

Universal Fitment

THIS MANUAL IS FOR USE WITH PART NUMBER 63341

banks

Section 1: **ASSEMBLY**

- 1.** Before starting work, familiarize yourself with the installation procedure by reading all of the instructions.
- 2.** The exploded views (**Page 3**) provides only general guidance. Refer to each step and section diagram in this manual for proper instruction.

1.0 Assembly

- 1.** Assemble the **Arm** to the **Base** in the orientation shown in **Figure 1**. Tighten **Nut A** finger tight.
- 2.** Install the **Cup** to the **Arm** in the orientation shown in **Figure 1**. Tighten **Screw B** lightly using the supplied hex key wrench.
- 3.** Insert the Gauge into the **Cup**. Do not use the sleeve and nuts provided with the gauge. If the gauge will not fully insert, loosen **Screw B** until the gauge can be full inserted.
- 4.** Use the provided alcohol wipe to clean the mounting surface. The suction cup can be mounted to the windshield as well as most dashboards.
- 5.** To mount the suction cup, remove the protective film. Start with the Base locking tab in the up position, push down firmly on the **Base** to the mounting surface, then push the locking tab down to secure the **Base**.
- 6.** Adjust the angle appropriately for your vehicle then tighten **Nut A** finger tight and **Screw B** using the provided hex key.

Section 2: **EXPLODED VIEW**

Figure 1, Exploded View

