



Part#: 124456

Product: Rear Sway Bar Link Kit

Application: 2007-2008 Jeep Wrangler JK

**READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR
TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.**

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the rear sway bar links from the sway bar and the axle mount. Save the lower hardware.
3. Lightly grease and install the provided steel sleeves (62147) into the pre-installed bushings in each end of the new sway bar links (92025).
4. Attach the sway bar links to the outside of the axle mount with the original hardware and to the outside of the sway bar with 12mm x 60mm bolts, nuts and washers. Run the upper bolts from the outside in. Torque all sway bar link hardware to 60 ft-lbs.
5. Check all hardware for proper torque after 500 miles.