



Part#: 128309

Product: **Rear Sway Bar Links**

Application: **Toyota FJ Cruiser**

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

SAFETY WARNING BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/ reassembly procedures and post installation checks must be known.

INSTALLATION INSTRUCTIONS

1. Park the vehicle on a clean, flat surface and block the rear wheels for safety.
2. Disconnect the rear sway bar links, retain bushings / washers for later use.
3. Install new sway bar links with new lower hourglass shaped bushing and sleeve. Attach with 12mm x 60mm bolt with 7/16" USS (large outside diameter) washers, and nut (BP #518). Attach top of sway-bar link with O.E. bushings / washers and new 5/16" nylock nut. Tighten 5/16" nut until bushings begin to swell, torque 12mm hardware to 45 ft-lbs.

ⓘ Note: This accessory uses a common bolt pack with the main suspension lift kit. You will have extra fasteners when the installation is complete.

PARTS LIST

Part #	Qty	Description
518	1	Bolt Pack
01434	2	Rear Sway Bar Links
SB58RB	2	Sway Bar Link Bushing
62147	2	0.625 x 0.075 x 1.375 Sleeve