



866-926-2867

Email: info@blackhorseoffroad.com

Mon-Fri 9AM-6PM EST

Headquarters

39 ST. MARY'S PLACE FREEPORT, NY 11520

INSTALLATION INSTRUCTIONS

RUSFB01

[Fit 2021+ Ford Bronco Sport]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 2 1¼ Screws
- 2 2" Screws

Tools Needed:

Impact drill or Socket wrench

Setting the lock password

Warning: To avoid locking yourself out, first set the password with the SAFE DOOR OPEN and test the operation of the lock before closing the safe door.

Safe installation:

STEP 1 Put both rear seat backs in the up position. Open the passenger side seat cushion by lifting the very top, exposing the storage compartment. Remove any contents of the storage and the plastic liner.

STEP 2 With the door in the open position, remove the padding from the safe, carefully slide in the safe body and ensure that the safe is seated all the way down into the rear seat compartment.

STEP 3 Insert the 2, 1¼" SCREWS into both **sides** insert studs and the 2, 2" SCREWS into both **front** insert studs. Then using a Socket Wrench, complete tightening until all screw heads fully contact the insert nuts, and **STOP!**

STEP 4 Tighten the bolts, **DO NOT OVER-TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**

STEP 5 Re-insert the padding that was removed from the safe before installation.