



OUTLAW SLIDER PREP INSTRUCTIONS

1. Every 3 to 4 weeks remove ½ male rod end from bottom of threaded tube and flush with clean solvent.
2. Pull the shaft out, put clean oil on the shaft, work the shaft in and out to lube the seal.
3. Add 1 tablespoon of 30w Mobil 1 Synthetic motor oil, (**DO NOT USE GREASE, WD-40, OR ANTISEAZE IT WILL CAUSE BEARING FAILURE.**) Install male rod end be sure to use Teflon thread tape on rod end to prevent leaking.

REPLACEMENT PART LIST

#7504 5/8" SHAFT
#7504-2 5/8" SHAFT 2" LONGER
#7506 1 ½" NUT
#7508 BEARING
#7509 DOUBLE LIP SEAL
#7512 PLUNGER
#7513 1" SNAP RING
#7514 9/16" SNAP RING
#7518 REBUILD KIT
#7518-2 REBUILD KIT 2" LONGER

SPRING CUPS

#7502 SLOTTED
#7503 TOP PLATE

LYNCH CLIP

#7516

WRENCH

7510

BSB MFG WILL REBUILD/REPAIR ALL OUTLAW SLIDERS FOR THE COST OF REPLACEMENT PARTS.