Directions:

Dual Action Polisher

Shake well and apply 4-5 drops to desired pad. Prime pad with Pad Conditioner. Dab product out evenly across 2' x 2' section. Turn on the machine on paint to speed setting 1 to spread product. Increase speed to 5-6 and using moderate pressure, work area in 2-3 passes until the product becomes clear. Follow with light pressure to finish. Remove residue with a clean microfiber towel.

Rotary Polisher

Shake well and apply 4-5 drops to desired pad. Prime pad with Pad Conditioner. Dab product out evenly across 2' x 2' section. Turn on machine away from the paint to a setting in between 1000-1500 RPMs to spread product. Using just the weight of the machine (no pressure) work area in 3-4 passes until the compound becomes clear. For the final pass adjust the speed setting to between 1200-1800 RPMs. Work until optical clarity is achieved. Remove residue with a clean microfiber cloth. For precision showroom results, finish with Chemical Guys P4 Polish.

Time	Expertise	Prep	What Else You'll Need
1 - 5 Hours	Advanced	Wash Surface, Decontaminate, Wipe Out	● <u>Dual Action or Rotary Polisher</u> ● <u>Microfiber or Foam Polishing Pads</u> ● <u>Microfiber Towels</u>
			Pad Conditioner HEX Logic Hand Applicator Pads