



INSTALLATION OF DELTA LED BLINKER LIGHTS P/N 01-6575-50



- 1) DECIDE WHERE YOU WANT TO PLACE YOUR LED SIGNAL LIGHTS. POPULAR LOCATIONS ARE ON THE FRONT FENDERS OR THE MIRROR HOUSINGS.
- 2) APPLY MASKING TAPE TO THE AREA YOU WISH TO ADD THE SIGNAL LIGHTS AND MARK YOUR SERIES OF $\frac{3}{4}$ INCH HOLES TO DRILL.
- 3) DEPENDING ON WHAT KIND OF MATERIAL YOU ARE DRILLING INTO, USE A $\frac{3}{4}$ INCH HOLE SAW AND MAKE YOUR HOLES. (NOTE: $\frac{3}{4}$ IS THE HOLE SIZE FOR THE RUBBER GROMMET)
- 4) SIMPLY WORK THE GROMMET INTO THE HOLES YOU JUST DRILLED. IT IS EASIER TO REMOVE THE LIGHT FROM THE GROMMET AND INSTALL THE GROMMET SEPERATLY THEN SLIP THE LIGHT IN.
- 5) NEXT, EXTEND THE WIRE LEADS, WITH THE SUPPLIED WIRE, AND RUN YOUR RED POSITIVE TO 12V SIGNAL LEAD AND THE BLACK TO A GOOD GROUND SOURCE.
- 6) DOUBLE CHECK ALL CONNECTIONS AND TEST YOUR LIGHTS.

