



Thank you for your purchase of our new LED Pod Ditch Light Kit. CAD-designed to use existing mounting points, this kit is compatible with the 2018+ Subaru Crosstrek. Basic installation instructions are included below. **Please contact us if you have any questions.**



1. Mark the location of the hood hinges with tape and tape the edges of the hood to prevent scratching.



2. Remove the two 12mm bolts securing the hood hinge, while holding the back of the hood.



3. Place the ditch light bracket under the hinge and align the holes with the hood hinge. Adjust the bracket to leave a slight gap at the back of the hood before tightening.

*See back for further instructions.*



4. Secure the bracket and hood hinge using the factory bolts, ensuring the hood hinge lines up with the tape.



5. Remove the tape and repeat the steps on the other side to complete the installation.



6. Once the bracket is mounted to the hood, refer to the Universal Bracket Info/Mounting Guide, to mount your pod onto the bracket.

**NOTE:** Do not use automatic car washes with this kit installed.

### This installation guide is for the following SKUs:

DD6557 Crosstrek 2018+ Ditch Light Brackets  
 DD6558 Crosstrek 2018+ Ditch Light Kit SS3 Sport White Driving  
 DD6559 Crosstrek 2018+ Ditch Light Kit SS3 Sport Yellow Driving  
 DD6560 Crosstrek 2018+ Ditch Light Kit SS3 Pro White Driving  
 DD6561 Crosstrek 2018+ Ditch Light Kit SS3 Pro Yellow Driving

DD6562 Crosstrek 2018+ Ditch Light Kit SSC2 Sport White Combo  
 DD6563 Crosstrek 2018+ Ditch Light Kit SSC2 Sport Yellow Combo  
 DD6564 Crosstrek 2018+ Ditch Light Kit SSC2 Pro White Combo  
 DD6565 Crosstrek 2018+ Ditch Light Kit SSC2 Pro Yellow Combo

**100% SATISFACTION  
 GUARANTEE**



[View other off-road lights made by Diode Dynamics on our website.](#)