

Application Instructions

- 1. Ensure surface is clean.
- 2. Mist distilled water on a panel.
- 3. Lightly shake the Formula 1201 bottle.
- **4.** Place 10 to 15 drops onto applicator. (For subsequent panels, apply 5-6 drops)
- 5. Apply to wet panel in circular or straight back-and-forth motions.
- 6. Immediately wipe panel down with a fresh microfiber towel.
- 7. Flip towel over to a dry section and hand buff until surface is glossy.
- 8. Repeat steps 2-7 until entire vehicle is covered, applying

5-6 more drops with each panel.

Additional Tips

Do not wash vehicle for 7 days after applying.

Product may require 2 weeks of cure time before reaching optimal effectiveness.

Do not apply in direct sunlight.

Do not allow this product to freeze during storage. Before applying, test a small amount in an inconspicuous place to check compatibility with surface.