



# Self-Adhesive Magnetic Plate Mounting Kit

## **WARNING!**

Failure to install or use this product according to manufacturers recommendations may result in property damage, serious bodily/personal injury, and/or death to you and those you are seeking to protect!



**Do not install and/or operate this safety product unless you have read and understand the safety information contained in this manual.**

1. Proper installation combined with operator training in the use, care, and maintenance of emergency warning devices are essential to ensure the safety of you and those you are trying to protect.
2. Exercise caution when working with live electrical connections.
3. Proper placement and installation are vital to the performance of this warning device. Install this product so that output performance of the system is maximized and the controls are placed within convenient reach of the operator so that s/he can operate the system without losing eye contact with the roadway.
4. It is the responsibility of the vehicle operator to ensure during use that all features of this product work correctly. In use, the vehicle operator should ensure the projection of the warning signal is not blocked by vehicle components (i.e., open trunks or compartment doors), people, vehicles, or other obstructions.
5. The use of this or any other warning device does not ensure all drivers can or will observe or react to a warning signal. Never take the right-of-way for granted. It is your responsibility to be sure you can proceed safely before entering an intersection, driving against traffic, responding at a high rate of speed, walking on or around traffic lanes.
6. This equipment is intended for use by authorized personnel only. The user is responsible for understanding and obeying all laws regarding warning signal devices. Therefore, the user should check all applicable city, state, and federal laws and regulations. The manufacturer assumes no liability for any loss resulting from the use of this warning device.

## **Installation:**

1. Find flat surface on vehicle roof, clear of ridges/bumps.
2. Thoroughly clean the mounting surface with alcohol pad supplied, ensure that it is dry.
3. Remove backing from adhesive strips.
4. **Ideal application temperature is 70°F-100°F, if it is colder than 85°F, use heat gun to warm adhesive. Do not heat past blistering. Application temperature has a large effect on how quickly full bond is achieved.**
5. Place plate with arrow pointing to the front of vehicle.
6. Apply firm, uniform pressure to plate to ensure full contact of adhesive. (15 PSI is ideal)
7. Wait at least 20 minutes before applying load.
8. This is a single-use mount. It must be replaced if it is removed from initial installation