



X-ACT CONTOUR


FLOOR LINERS

CARE AND USE INSTRUCTIONS 53921

Thank you for selecting X-act Contour® Floor Liners from Winfield Consumer Products. Your new rear seat floor liner is custom molded to fit your Chevrolet Colorado or GMC Canyon Extended Cab. The liner is made to take the place of your factory floor mats. ***For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner. However, do not remove the factory-installed carpeting.***

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR YOUR COLORADO & CANYON EXTENDED CAB 2ND SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR COLORADO / CANYON SECOND SEAT LINER, MOVE THE FRONT SEATS TO THEIR MOST FORWARD POSITIONS. WITH THIS DONE, INSERT LINER IN VEHICLE ANGLING THEM SO THAT THE FRONT EDGE OF THE LINER IS SEATED INTO PLACE FIRST, THEN LOWER THE REAR OF THE LINER. ONCE THE LINER IS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.