





STEP 1

Unroll your Custom Auto Shade™ with the reflective side facing outward and place it as flat as possible onto the dash area. If there are assist handles on the windshield pillars, make sure the Sun Shade fits in front of them. Then slide it forward until it reaches the bottom of the windshield ahead of the defroster vents.



STEP 2

With both hands, lift the top of the Custom Auto Shade™ into the windshield area. NOTE: Be careful to not bend the corners while installing, as damage to the inner insulator may occur.



STEP 3

Pull down each sun visor to hold the Custom Auto Shade™ in place. In some cases, the Sun Shade may not reach all the way to the windshield pillars. This additional space is necessary to be able to install the Sun Shade without damaging it.



REMOVAL

Simply reverse the installation steps, roll up the unit with an attached velcro strap and store in the trunk.