



## HOW TO INSTALL YOUR CUSTOM AUTO SHADE™

Every CUSTOM AUTO SHADE™ will fit differently as there are differences in every vehicle.



STEP 1: Unroll the CUSTOM AUTO SHADE™ across dash. Make sure the CUSTOM AUTO SHADE™ is centered in the windshield and placed down, where the glass meets dash.



STEP 2: Tuck the CUSTOM AUTO SHADE™ behind rear view mirror, if mounted on windshield.



STEP 3: Lift the CUSTOM AUTO SHADE™ against glass. Adjust the CUSTOM AUTO SHADE™ in windshield, may overlap slightly with side windshield frame (A-pillars) and headliner.



STEP 4: Lower sun visors for support.



hook and loop fastener strap included



[View other windshield sun shades and snow covers made by Intro-Tech Automotive on our website.](#)