



## HOW TO INSTALL YOUR ULTIMATE REFLECTOR™ CUSTOM FOLDING AUTO SHADE

Every ULTIMATE REFLECTOR™ CUSTOM FOLDING AUTO SHADE will fit differently as there are differences in rear-view mirror mount locations, windshield frame (A-pillar) designs, headliners and dash designs, as well as windshield shapes and sizes.



STEP 1: Unfold the ULTIMATE REFLECTOR™ CUSTOM FOLDING AUTO SHADE with the silver side facing outward and place it flat onto the dash area. Then slide it forward.



STEP 2: Lift the top of the ULTIMATE REFLECTOR™ CUSTOM FOLDING AUTO SHADE into the windshield area.



STEP 3: Pull down each sun visor to hold the ULTIMATE REFLECTOR™ CUSTOM FOLDING AUTO SHADE in place.



Storage bag included

[View other windshield sun shades and snow covers made by Intro-Tech Automotive on our website.](#)