

INSTALLATION INSTRUCTIONS

LODESTAR 750L HIGH-OUTPUT DRIVING LIGHTS

3008 SPOT BEAM OR 3009 FLOOD BEAM

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

⚠ WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

⚠ CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

| | | | |
|---|---------------|---|---------------------|
| 2 | Driving Light | 2 | Hex Head Cap Screws |
| 2 | Wire Adapters | 2 | Flat Washers |
| | | 2 | Lock Nuts |

YOU WILL ALSO NEED:

Hex socket set, ratchet, wire strippers/crimpers

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

NOTICE

DRIVING LIGHTS ARE NOT DOT CERTIFIED. USE SHOULD BE LIMITED TO OFF ROAD SITUATIONS ONLY.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

⚠ CAUTION AVOID POTENTIAL ELECTRICAL SHOCK! DISCONNECT THE BATTERY BEFORE STARTING THIS PROCEDURE.

STEP 2 Disconnect the ground terminal on your battery.

STEP 3 Locate provided Driving Lights and Wire Adapters. Connect the adapters to the lights.

STEP 4 Locate provided mounting hardware. Determine where provided lights will be mounted, and loosely mount them in place. Doing this will help you determine if wiring adjustments need to be made.

STEP 5 Locate a keyed 12-volt power source and a ground wire source.

Note: Refer to your vehicle's service manual or wiring schematic for assistance in identifying wires. Each light draws 1.1 Amps. Confirm the power source selected can handle the additional load.

STEP 6 Connect the red wire from the adapter to the keyed 12-volt power source, and the black wire to the grounded wire source.

P/N 3008: SPOT BEAM



PIC 1

P/N 3009: FLOOD BEAM



PIC 2

INSTALLATION INSTRUCTIONS

LODESTAR 750L HIGH-OUTPUT DRIVING LIGHTS

-CONTINUED-

STEP 7 Reconnect the battery, turn vehicle on, and test the lights for proper operations before driving. After testing the lights, turn the vehicle off.

STEP 8 Double check all wiring connections.

STEP 9 Aim your lights by loosening the hardware connecting the light to the mounting bracket.

STEP 10 Tighten all hardware.

STEP 11 Secure all cords in a safe place. Ensure that cords are secured away from any moving parts, excessive heat or pinch points.

NOTICE

SECURE ALL WIRING AWAY FROM ANY MOVING PARTS, PINCH POINTS OR EXTREME HEAT. KURYAKYN WILL NOT ISSUE A WARRANTY ON ANY ELECTRICAL COMPONENT THAT FAILS DUE TO PINCHED, CRIMPED, BROKEN, ABRADED, MELTED OR FRAYED WIRES.

STEP 12 Retest function of lights. Ensure all of the lights properly function before operating vehicle.

WARNING

ENSURE PROPER LIGHT OPERATION BEFORE DRIVING THE VEHICLE. VISIBILITY IS A MAJOR CONCERN FOR DRIVERS. A LIGHT MALFUNCTION COULD RESULT IN DEATH OR SERIOUS INJURY.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.