



Bolt the Roll-off mounting bolts into the rear of both levelers.
Blue Loctite is recommended

