




INSTALLATION INSTRUCTIONS



'13-'15 TOYOTA TACOMA V6 4.0L | PART NO. 17147

BILL OF MATERIALS:



1. **INLET PIPE ASSEMBLY**
2. **MUFFLER ASSEMBLY**
3. **TAILPIPE ASSEMBLY**



WEAR SAFETY
GLASSES



READ INSTRUCTIONS
THOROUGHLY BEFORE
INSTALLING PRODUCT

SHOP SUPPLIES:



SPRAY LUBRICANT

To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.

HARDWARE KIT:

1. [2] 2.50" Clamp

MINIMUM REQUIRED TOOLS:




15mm



Hanger Tool
(Or Pry Bar)


INSTALLATION INSTRUCTIONS



Step 1. Begin removal of the OEM exhaust system by unbolting the two spring loaded bolts attaching the exhaust to the catalytic converter. Do not discard or damage the OEM fasteners or rubber insulators as they will be used to install the new system.



Step 2. Disengage hangers from rubber insulators and remove the OEM exhaust.



Step 3. Begin installation of your new MAGNAFLOW system by attaching the Inlet Pipe Assembly to the catalytic converter outlet using the OEM fasteners and insulator. Keep all fasteners and clamps loose until final adjustment.



Step 4. Next use the supplied 2.50" clamps to attach the Muffler Assembly to the Inlet Pipe and the Tailpipe Assembly to the Muffler Assembly. Complete by fitting the hangers on the Tailpipe into the insulators.



Step 5. Once a final position has been chosen for the new exhaust system, evenly tighten all clamps from front to rear using the torque specifications on page one of the instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.