


2004 Dodge Hemi Single Tailpipe SC/CC



Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

Step 1: (Carefully read all instructions before installation) Disconnect the vehicle's battery before removal of the OEM exhaust. This will allow the computer to reset itself with the new system, and prevent electrical accidents.

Step 2: Start at the Front of the OEM System and work your way back. Unbolt and Remove the OEM System. Then Install your New Magnaflow Performance Exhaust System. First slide the supplied 2.75" U-bolt over the OEM pipe that comes from the OEM Catalyst before installing the muffler assy. Then move the Tailpipe Ext. into place and put the new hangers into the Oem insulators. Lastly, put the Tailpipe Assy. on the Tailpipe Ext. and move into place.

Step 3: With all components mounted loosely, adjust the system for overall aesthetics and clearance of frame & bodywork. (MAGNAFLOW recommends at least 1/2" of clearance between the exhaust system and any body panels to prevent heat-related body damage or fire.)

Step 4: Once a final position has been chosen for the new system, evenly tighten all fasteners from front to rear. Inspect all fasteners after 25-50 miles of operation and retighten if necessary.

**MAGNAFLOW Performance Exhaust recommends professional installation on all their products*