



71-6522

INSTALLATION INSTRUCTIONS

**2007-UP CHRYSLER /
DODGE AND JEEP
WIRE HARNESS INTO
OEM RADIO**



PIN	COLOR	FUNCTION
1	Yellow	Battery (+)
2	Blue/Pink	CAN BUS (-)
3	Black/Green	UCI Power Feed 2 Pass through (Navigation)
4	Black/Yellow	UCI EXT Receive (Navigation)
5	Blue/Green	UCI EXT Transmit (Navigation)
6	Blue/Red	UCI Device Detect (Navigation)
7	Blue	Power Antenna
8	Green	Left Rear Speaker (+)
9	Green/Black	Left Rear Speaker (-)
10	Purple	Right Rear Speaker (+)
11	Purple/Black	Right Rear Speaker (-)
12	Black	Ground
13	Pink	CAN BUS (+)
14	Blue/Yellow	Ground/(Navigation)
15	Brown/Red	UCI Audio Reference (Navigation)
16	Green/Orange	UCI Audio Left Input (Navigation)
17	Gray/Blue	UCI Audio Right Input (Navigation)
18	Green/Red	Not Used
19	Gray	Right Front Speaker (+) Non-Amplified
20	Gray/Black	Right Front Speaker (-) Non-Amplified
21	White	Left Front Speaker (+) Non-Amplified
22	White/Black	Left Front Speaker (-) Non-Amplified