

HOW TO USE:



Step 1:
Dilute Blue Dress with water with a 1:1 mix ratio with water.



Step 2:
Add water to Blue Dress to create a 1:1 mix ratio with water.



Step 3:
Spray a generous amount of mixed Blue Dress onto applicator pad.



Step 4:
Spray mixed Blue Dress on tire if pre-coverage is necessary.



Step 5:
Spread and level Blue Dress over the tire face.

