

HOW TO USE:



Spray sufficient amount of Glide on the glass and paint surface. NOTE: Do not allow the lubricant to run dry on the surface.



With light to medium pressure use the Autoscrub in a back and forth motion. Work in a 12"x 12" area at a time. *Do not allow Nano Shock to dry on the surface



Spray sufficient amount of lubricant on the plastic surface. NOTE: Do not allow the lubricant to run dry on the surface.



With light to medium pressure use the Autoscrub in a back and forth motion. Work in a 12"x 12" area at a time. *Do not allow Nano Shock to dry on the surface.



After every step, wipe surface dry using a soft micro fiber towel

[View other auto detailing and care made by Nanoskin on our website.](#)