

## Install - Sprint

### Installation Instructions for Sprint Speed Screen



1. Starting with the Speed Screen and Rail together, place the [Speed Screen system](#) behind the air dam cross member.



2. Using a Zip Tie through the holes in the rail strip, loosely attach to the chassis of the car, starting with the top above the cross member on both sides, and then the middle on both sides, and then the bottom on both sides.



3. Once the Speed Screen is attached to the chassis, tighten down all Zip Ties drawing the Speed Screen nice and taut.



4. With the Speed Screen firmly attached to the chassis, the screen can now fully protect the radiator and be easily removed and re-installed for cleaning.