

BRAKE BLEEDER KIT

1. Fill master cylinder with new brake fluid and keep it full during bleeding operation.
2. Assemble bleeder kit with short hose attached inside lid and long hose outside lid on the same fitting as short hose.
3. Remove bleeder screw from wheel cylinder and clean.
4. Check the three adaptor tips included and select one that best fits bleeder screw. Attach to end of long hose.
5. Replace bleeder screw finger tight, then unscrew 1-1/2 turns and connect to adaptor.
6. Pump brake pedal slowly, then check hose for air bubbles.
7. Continue until there are no bubbles in hose.
8. Remove bleeder kit and firmly tighten bleeder screw.
9. Repeat procedure for remaining wheels.



WARNING! Brake fluid is corrosive. Avoid contact with painted surfaces, clothing, skin and eyes. Wear eye protection. Follow vehicle manufacturer's sequence order for bleeding brake lines. If you jack vehicle up, **BE SURE TO USE JACK STANDS!**

PT
Performance Tool®