



**Door Handles 87500**  
**2007-2010 Jeep Wrangler 2Dr & 4Dr**

## **Installation Instructions**

**Parts List:**

- 1- Door Handle**
- 2- 5mm Nylock Nuts**
- 2- 5mm Flat washers**

**Installation:**

**1) Front and Rear Doors**

- a) Remove Door panel (See dealer for instructions)
- b) Hold handle and remove front and rear nuts, pull handle off outside of door.
- c) Remove front and rear rubber gasket from factory handle and replace on new cast handle.
- d) Make sure all screws on handle are tight.
- e) Replace handle on door and tighten with Nylock nuts and washer provided.
- f) Replace Door panel.

**2) Tailgate**

- a) Remove Rear inspection cover See Fig.1
- b) Remove clevis clip from handle plunger. See Fig 2.
- c) Hold handle and remove Top and Bottom nuts, pull handle off outside of door.
- d) Remove front and rear rubber gasket from factory handle and replace on new cast handle
- e) Remove two screws from plunger on factory handle with clevis clip, not the position of the clip.
- f) Remove two screws on new cast handle from plunger and replace with Round factory clevis clip plate. Be sure to install in the correct position.
- g) Replace handle on door and tighten with Nylock nuts and washer provided.
- h) Reconnect clevis clip from handle plunger. See Fig 2.
- i) Replace inspection cover.



Fig 1.



Fig2.