



#73809

## ***2" Amber Clearance/Marker Light***

***Snap-in lens, mounting bracket  
Designed for 12-volt systems.***

### ***INSTALLATION:***

1. Disconnect the battery.
2. Use the angle bracket as a template to mark mounting holes for the screws.
3. Attach a lead wire to the positive (+) headlamp circuit.
4. Drill two 1/8" diameter holes and mount the angle bracket to grounded surface with two sheet metal screws.
5. Reconnect the battery.