

## Installation Instructions for 450-43LE Solenoids

- 1. Remove old solenoids.
- 2. Insert new solenoid assemblies into valve body.
- 3. Plug in original wire harness as shown in illustration.

## NOTE: Be aware that the solenoid may rotate during normal operation. Position lead wires away from moving parts.

- 4. Slide mounting bracket over locating post on solenoid.
- 5. While holding mounting bracket in position, attach black ground wire and mounting bolt to valve body. Make sure solenoid and bracket are correctly positioned before tightening mounting bolts.

