

# SOUTHERN TRUCK

Lift your life.

**2007-Current Ford-Chevy-GMC 2WD/4WD  
0.25" Wheel Spacer; 6x5.5"; 6x135mm**

# 95000

2 - 1/4" Wheel Spacers

## PRE-INSTALLATION

**Professional installation by a certified technician is strongly recommended.**

*Not responsible for altered products. No claims are made regarding any lifting devices. Any and all claims implied in this document excluded.*

### NOTES:

Check spacers regularly to ensure tightness.

### REQUIRED TOOLS:

Floor Jack

Jack Stands

Torque Wrench

Socket Set

Socket Wrench

## INSTALLATION INSTRUCTIONS

**STEP 1:** Chock tires to avoid vehicle roll. Jack up vehicle so that wheels are just off the ground.

**STEP 2:** Remove all lug nuts. (Socket wrench)

**STEP 3:** Remove wheels/tires.

**STEP 4:** Check for factory retaining clips and remove if present. Wheel spacer must sit flat against the rotor. Vibrations may occur if clips are not removed from wheel studs.

**STEP 5:** Install wheel spacers on studs.

**STEP 6:** Re-install wheels/tires.

**STEP 7:** Re-install lug nuts and tighten to factory specs. (Torque wrench) **DO NOT OVERTIGHTEN**

## POST-INSTALLATION

**MAINTENANCE:** Wheel lug nuts should be re-tightened to factory torque specs. periodically. Always inspect components and re-tighten lug nuts during routine service.

Learn more about wheel spacers and adapters we have.