

SOUTHERN TRUCK

Lift your life.

1987-2015 Jeep Wrangler Spare Tire Adapter/Spacer

95006

1 - Spare Tire Bracket 3 - 1/2" Flat Washers
3 - 1/2" Lock Nuts 1 - 9/16" Flat Washer
1 - 1/2" Non-Locking Nut

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any lifting devices. Any and all claims implied in this document excluded.

NOTES:

Intended for tires up to 33"x12.50 - larger tires may damage rear gate. Check hardware regularly to ensure tightness.

REQUIRED TOOLS:

3/4" Socket 3/4" Wrench

INSTALLATION INSTRUCTIONS

STEP 1: Remove spare tire. (3/4" Socket)

STEP 2: Install studs in spacer bracket, matching factory bolt pattern.

STEP 3: Use non-locking nut and 9/16" flat washer to fully tighten each stud. (Impact wrench and 3/4" socket)

STEP 4: Remove non-locking nut and washer and discard.

STEP 5: Install spare tire bracket on factory studs. Secure with supplied lock-nuts and washers. (3/4" wrench)

STEP 6: Re-install spare tire.

STEP 7: Re-install factory lug nuts and tighten (3/4" socket)

POST-INSTALLATION

MAINTENANCE:

Re-tighten lug nuts after 500 Miles.

Wheel lug nuts should be re-tightened to factory torque specs. periodically. Always inspect components and re-tighten lug nuts during routine service.