

SPEC-D *Tuning*

2007-2010 CHEVY SILVERADO LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

TOOLS AND SUPPLIES REQUIRED

Trim Pad remover

Phillips Screwdriver

Handy Remover

Product Part Numbers:

LT-SIV07CLED-TM

LT-SIV07GLED-TM

LT-SIV07JMLED-TM



2007-2010 CHEVY SILVERADO LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.



1. Remove the (2) Phillips head screws



2. Remove the tail light



3. Remove the harness and bulbs from the tail light



4. Remove the (2) plastic holders from the tail light



5. Plastic holder



6. Replace the plastic holder onto the mounting holes



7. Remove (2) light bulbs from harness, brake, and signal lights



8. Tail light harness

please see the " L.E.D. tail lights installation instruction"
If your tail lights don't have L.E.D. You can skip the installation instruction.



8. Connect the LED tail light connector into the tail light harness



10. Place the socket into the LED tail light assembly



11. Place the LED tail light onto the vehicle



12. Replace the (2) phillips head screws



13. Please repeat the steps in order from 1 to 12 for the opposite side



14. The installation is now complete

