

ASSEMBLY INSTRUCTIONS**Tools Needed for Assembly:**

14mm Wrench

Assembly Instructions:

1. Attach all five (5) casters to bottom of round metal base. The bottom of the base is opposite the side with the center round hole. Insert the threaded stem of each caster through each of the holes, add washers and tighten nuts onto stems with a 14mm wrench.
2. Insert the painted end of the lift cylinder into center hole on top of round metal base. To avoid damaging the cylinder, do not force or hammer cylinder into the hole.
3. Place seat on top of the unpainted end of the lift cylinder. As with the lift cylinder in Step #2, do not force or hammer the seat onto the cylinder.
4. To lock seat and cylinder into place, slowly add your weight to the seat by sitting on the seat for approximately 10 seconds. The cylinder and the seat will lock into place automatically.

Care Instructions:

Your professional shop seat is designed to give you worry-free service with little to no maintenance. There should be no need for periodic oiling or maintenance of the seat or cylinder. Simply clean with a damp cloth. Avoid contact with harsh chemicals.

- Replacement air cylinder available as part # RSTSAC
- Replacement caster with washer and nut available as part # RS8515CS
- Replacement plate with seat lever available as part # RS8509SLTS

