

21117/B
14-15 CHEVY
SILVERADO 1500



21117/B
14-15 CHEVY
SILVERADO 1500

CHEVY SILVERADO 1500

Billet Series Grille

TOOLS REQUIRED:

Flat/Phillips Screw Drivers

PARTS LIST:

(8) 2" Machine Screws

(8) Wing Toggle Clip



Step 1

Grille installation

Insert the machine screws through the front of the billet grille and through the small black square tabs that are welded to the back side of the billet grilles. Install the wing clip on the end of the screws (Fig 2). Place the billet grille into the factory grille opening, use a flat screwdriver to turn the wing toggle clip so that it inserts into the factory grille behind the honeycomb (Fig 3). Hold the wing toggle clip with a screwdriver to keep it from turning while you tighten the machine screws. Repeat on the second grille. Installation complete.

