

## UNIVERSAL

### Baja Bars

Install time: 15 Mins.

**TOOLS REQUIRED:**

Rubber Mallet  
Socket wrench

**PARTS LIST:**

(2) Baja Bars  
(4) 10/32 Nylon Lock Nuts  
(4) 1/4 Lock Washers  
(4) Plastic Covers

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

**Step 1 Stud Removal**

• Look at where you're going to put the Baja Bars then With a Plastic Mallet, Remove the Stud. (Fig. 1)

**Step 2 Bar INSTALLATION**

- Place the Plastic Covers onto the Threaded Studs on the Baja Bar. (Fig. 2)
- Place Baja Bar onto the opening holes where you removed the Studs. (Fig. 3)
- Place a Fender Flatwasher and Nylon Lock Nut on the Threaded Stud. (Fig. 4)

**INSTALLATION COMPLETE**

