



MKT001 MACK

Rear suspension package

Ref. = Reference

Part = Part #.

Qty. = Quantity

INSTALLATION INSTRUCTIONS

- a) Raise vehicle allowing the axle to hang freely.
- b) Remove existing bump stop assembly.
- c) Assemble Aeon rubber spring and bracket as shown in the adjacent diagram.
- d) Mount Timbren assembly using existing holes & Timbren supplied fasteners.
- e) Lower vehicle.

Qty F33007-150 F40071-020 F11108-150 K10006-003 2L-2R F11142-150 A16110-003 A16040 A00560-55C70 4 F31005-150 MKT001 TIMBREN

Do not exceed vehicle manufacturer's recommended axle weight rating. Check for AEON® interference with vehicle components - Under load AEON® will "expand" in diameter.

MKT001

PART NUMBER	DESCRIPTION	QTY	LOCATION
F31007-150	NYLOCK LOCKNUT 5/8 UNF GR 5 Z	8	H2E
F40071-020	WASHER FLAT USS 5/8 x 1-3/4 GR 2 Z	8	H2E
F11142-150	HCS 5/8 x 1-1/2 UNF GR 5 Z	8	H2E
F31005-150	NYLOCK LOCKNUT 1/2 UNF GR 5 Z	4	G1D
F11108-150	HCS 1/2 x 3 UNF GR 5 Z	4	G2A
A00560-55C70	Hollow Rubber Spring	4	C13A
K10006RH-003	IHRCXT/MKT001/MKTT001 WELD. RH PAINTED	2	E1A
K10006LH-003	IHRCXT / MKT001 / MKTT001 WELD. LH PAINTED	2	E1A
A16110-003	DISC 6 OD x 17/32 ID x 3/8 THK PAINTED	4	D20A
A16040	STEEL CUP 6-15/16 od x 17/32 id x 1-5/8" deep	4	D21B
B90223	10-3/4 x 9-1/2 x 7 DW Carton	2	A1A
B10100	NEWSPRINT 18" ROLL	1	
B00029-010	BARCODE LABEL FOR KIT	2	
	1 of 2 & 2 of 2 LABELS	1 ea.	

ASSEMBLY NOTES:

COMPONENTS ARE DIVIDED INTO LEFT / RIGHT AND PACKAGED IN SEPARATE CARTONS. IDENTIFY CARTONS AS LEFT OR RIGHT.

APPLY 'LEFT' LABEL TO L/H BRACKET.

APPLY "1 of 2" and "2 of 2" LABELS TO CARTONS

Issued: 9/9/2005

Clearance Instructions:

Rear SES Kits for Pick-Ups and Vans should have a 1/2" to 1-1/2" gap between the rubber spring and contact point when empty.

A partial load, or vehicle accessories will reduce or eliminate the gap.

Front SES kits are usually in full contact.

Medium and Heavy-Duty Trucks, Trailers and Motorhomes will be in constant contact, and have no gap.