



Protecting Your Adventure Lifestyle

3515 FJC Warrior Front Bumper Skidplate Installation Instructions

NOTE: This Skidplate is only compatible with the 3520 & 3530 Warrior FJC Front Bumper.

KIT CONTENTS:

Description	Qty	Description	Qty
Front Bumper Skidplate	1	_ Lock Washers	5
8mm x 20mm Stainless Steel Button Head Screws	7	_ USS Flat Washers	2
8mm Nuts	5		

INSTALLATION:

1. Locate and remove the two bolts that affix the front edge of the factory skidplate to the front cross member. You may reuse these bolts or use the hardware provided with the Warrior skidplate.
2. Set the Warrior skidplate into place with the bumper side edge set inside the front bumper. Loosely thread the hardware through both the bumper and the skidplate.
Note: On some early versions of the Warrior front bumper there may be some clearance issues with the two outermost mounting holes and the bumper's inner winch plate support structure. Utilizing a cut-off tool to cut the two outmost 8mm x 20mm screws shorter will alleviate this issue.
3. Push the skidplate into place so that the two lower mounting tabs set inside of the depressions in the front edge of the factory skidplate. Thread the remaining hardware into these two slots utilizing the _ flat washers. If the slots in the skidplate do not line up with the holes in the front cross member, check to make sure the front bumper is centered on the frame mount studs. Make any necessary adjustments then tighten all bolts.
4. The installation of your FJC Warrior Front Bumper Skidplate is now finished.

