



Warrior, Inc.  
16850 SW Upper Boones Ferry Rd. Suite A  
Durham, OR 97224  
Phone: (888) 220-6861  
Fax: (503) 692-0364  
[customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

## 2005-2015 Toyota Tacoma Sidesteps (4dr Double Cab)

4720

### Kit Contents:

<u>Item</u>	<u>Qty</u>	<u>Item</u>	<u>Qty</u>
8mm x 35mm Bolts	12	Split Lock Washers	12
Flat Washers	12	Sidesteps	2

### Installation Instructions:

1. Locate your [12] 8mm x 35mm bolts and add a Split Lock Washer on each bolt.
2. Add a Flat Washer to each bolt after the Split Lock Washer and set aside.
3. Remove factory side steps, if you have them. If you do not have factory side steps, locate and remove the three sets of two plastic plugs on the underside edge of the truck cab. To remove the plugs, simply unscrew them with a flathead screwdriver. Removing the plastic plugs will expose the factory threaded mounting points. (The front-most set of plugs are located approximately 8" behind the cab body mount. The middle set of mounting points are 30-1/4" behind the front points, and the rear mounting points are 37-3/8" behind the middle points.)
4. Position driver's side step with the mounts under the cab of the truck, and the largest mounting bracket toward the front.
5. Loosely thread 8mm x 35mm bolts with flat washers and split lock washers through the mounts and into existing factory threaded holes. Six bolts should be used per sidestep – 2 bolts used per mounting bracket.
6. Hand tighten, but make sure to leave them loose enough to visually align the step when nearing completion.
7. Visually align the steps then tighten all bolts.
8. Repeat steps 3-7 for passenger's side.
9. Installation Complete.

If you need further assistance installing your product, please contact us by email at [customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com) or call us at (888) 220-6861.