



Protecting Your Adventure Lifestyle

HALF DOORS
INSTALLATION INSTRUCTIONS
S916DOOR / 916DOOR
TJ WRANGLER 1997 - UP

Read all instructions before proceeding.

NOTE: Fits all applications where hard door striker pins and rotary paddle latch are used.

1. Assemble the door paddle handle, both sides, with bolt and nuts supplied.
2. On the inside of each door, install foam molding per Diagram "A".
3. Hang door on jeep and check for proper fit. Close door slowly onto paddle striker being sure that the paddle and striker line up correctly.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS