



Protecting Your Adventure Lifestyle

---

## WINDSHIELD LIGHT BRACKETS

### INSTALLATION INSTRUCTIONS

#### WAR 1515 - '76-'96 CJ & YJ WRANGLER

#### WAR 1510 - '97 & UP TJ WRANGLER & LJ UNLIMITED

Congratulations on your purchase of Warrior Products Windshield Light Bracket for your Jeep. Be sure to open the box and examine the contents before beginning. Read these instructions completely before starting your installation. (**NOTE: For CJ's only.** If you have a factory windshield hinge mounted mirror on your Jeep, and you want to retain it, you will want to purchase 8 –  $\frac{1}{8}$ "x  $\frac{1}{8}$ " NC bolts before strating and then follow the instructions below. If you do not have a windshield mounted mirror go directly to step #4 and observe step #6 when finished.)

1. The Warrior Light Bracket attaches to the front of your windshield, on the lower part of the windshield hinge. Place the enclosed pattern on your factory windshield hinge to ensure hole locations are the same. (Not all Jeeps are the same)
2. Place the enclosed pattern on the Warrior Light Bracket, mark hole locations and drill using a  $\frac{3}{8}$ " bit. Remember to use safety glasses when drilling.
3. You will want to apply some paint to the inside surface of the holes just drilled to prevent rusting. Spraying paint onto a cotton swab and using it as a small paintbrush works well for this.
4. Remove large bolts on windshield hinge and mount Warrior Light Bracket using two stainless steel bolts provided for each side. Remove one bolt at a time, CAREFULLY, to avoid dropping backing nuts located inside the framework.
5. Remount your mirror through the holes you drilled on the Light Bracket.

When finished, be sure to go back and check tightness of all bolts.