



CARB # PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon intake: 301-149**

US Patent# US 7,263,961B2

Application : **2003-05 HONDA ELEMENT**

**Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 10mm x 12" hose/ 1 x black grommet
1 x 6" x 1" hose / 1 x 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" clamp, 1 x 3" Coupler / 2 x 3" Clamp**

- 1 Remove the PVC emissions box from OEM tube, Disconnect the plastic EVAP hardline from OEM intake pipe.
- 2 Loosen the OEM airbox and rubber intake tube, disconnect the MAF sensor harness from OEM airbox
- 3 Remove the top portion of OEM airbox by unclipping from bottom portion.
- 4 Locate 10mm bolts securing bottom airbox to car and unbolt to remove bottom portion of airbox.
- 5 Disconnect AIT sensor harness, and 8mm OEM vacume from Oem tube and remove OEM tube.
- 6 Place the 3" - 3" coupler onto the throttle body and secure with the OEM clamp.
- 7 Place Weapon*R Intake Tube into the 3" end of the coupler and secure with clamp.
- 8 Install 1" hose onto 1" port on pipe, insert the PVC box into the 1" hose, secure with supplied clamps.
- 9 Install the 8mm hose onto the 8mm port on intake pipe and the plastic EVAP hardline on the engine .
- 10 Install black grommet into WR intake tube, and insert AIT sensor into grommet.
- 11 Reconnect AIT sensor harness to AIT sensor in WR intake tube.

- 12 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 13 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 14 Install U-shaped part of intake system bracket under the clamp on air filter.
- 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 17 Secure with washer and nut included in bracket kit.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

