



Recommended [Air Filter](#) Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon intake system: 305-155**

US Patent# US 7,263,961B2

Application : **1996-98 Toyota 4Runner / Toyota Truck V6**

**Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 3" / 3x 10mm x 12" Hose / 2 x 3" Coupler
1 x 2.5"-3" coupler/ 1 x Intake System Bracket kit / 3 x 3" Clamp / 1x 15mm x 12" Hose / 1x 3/8 " "T" fitting**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV & Air Recirculator valve hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove MAF sensor from OEM airbox,
- 4 Loosen the nuts holding the MAF to the OEM airbox, remove the MAF from the airbox.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert Weapon*R intake pipe into the 3" coupler, secure with clamp.
- 8 Measure the OEM PVC hose, replace with supplied 10mm hoses, use "T" fitting to install from PVC ports to intake pipe.
- 9 Install the 15mm hose onto the air recirculator valve and onto the Weapon*R intake pipe.
- 10 Install the 3" coupler onto the end of the intake pipe, secure with a clamp.
- 11 Install MAF sensor into the 3" coupler, reconnect MAF sensor harness, secure with clamp.
- 12 Install 2.5"-3" coupler onto MAF sensor and clamp down
- 13 Install the Secret Weapon air filter into the 3" side of coupler, secure with supplied clamp.
- 14 Install U-shaped part of intake system bracket under the clamp on air filter.
- 15 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 17 Secure with washer and nut included in bracket kit.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 20 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

