



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Secret Weapon: 306-117**

US Patent# US 7,263,961B2

Application : **2005-07 Subaru Forester / Impreza / Outback NT**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 2 x 10mm x 24" Hose / 1 x 2.75" coupler
1 x Intake System Bracket kit / 1 x 2.75"-3" Coupler / 5 x 3" Clamp / 1 x Grommet/ 1 x "T" Fitting

1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.

2 Remove the PCV hoses from OEM intake and engine.

3 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.

4 Remove MAF sensor from factory air box, install onto Weapon*R intake pipe with supplied hardware.

5 Wipe the throttlebody clean of any grease, install the 2.75" coupler onto throttlebody, secure with OEM clamp.

6 Insert Weapon*R intake pipe into the 2.75" coupler, secure with clamp.

Use vacume cap to cap off port on pipe closest to filter end of tube. **DO NOT USE THIS PORT FOR VACUME**

7 Measure from valve cover PCV port to intake pipe port. Replace with supplied 10mm hoses.

8 Use "T" fitting to crankcase PCV port to 10mm port on intake pipe. Replace with supplied 10mm hose.

9 **Special Note: Later models may have an AIT sensor, Drill a 3/8" hole on pipe from throttle body side about 4" away from end, insert & secure supplied grommet into drilled hole, and insert AIT sensor into grommet.**

Install the Weapon*R Hyper filter onto end of intake pipe.

10 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**

11 Stretch the 2.75-3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.

12 Install filter assembly onto the Weapon*R Intake Pipe, secure with clamp.

13 Install U-shaped part of intake system bracket under the clamp on air filter.

14 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.

15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.

16 Secure with washer and nut included in bracket kit.

17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.

18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.

19 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

