



Part# 601-129 SECRET WEAPON TRUCK INTAKE

US Patent# US 7,263,961B2

Application: 1997-02 WRANGLER 2.5L 4CYL

Parts List: 1 x 3" Weapon*R Air Filter / 2 x Weapon*R [Air Intake Tube](#) / 1 x 2.5"-3" Coupler / 2 x 3"-3" couplers
2 x 3" couplers / 1 x 15mm x 12" hose / 4 x Hose Clamps / 1 x Heat Shield Kit / 1 x Rubber Mounting Grommet / 5 x Black air box screws

- 1 Loosen both hose clamps holding the OEM intake tube, remove OEM intake tube.
- 2 Remove the valvecover breather tube from the OEM resonator box.
- 3 Remove the 2 bolts holding the OEM resonator box to the valvecover.
- 4 Loosen the clamp on the throttlebody located under the resonator box, remove resonator box.
- 5 Loosen the 5 clips holding the top of the OEM airbox, remove the airbox top and OEM air filter.
- 6 Remove the 3 bolts holding the lower half of the airbox, remove the lower airbox.
- 7 Remove the upper passenger side radiator mounting bolt for later use.
- 8 Install the rubber mounting grommet onto the airbox mounting hole near the battery.
- 9 Assemble heat shield by aligning holes #1 to #1 and so on, secure with screws in kit.
- 10 Install the heatshield in the airbox area, lining up the front radiator mounting point to the heatshield.
- 11 Bolt the heatshield in place, bolt the 2nd mounting point to the vehicle chassis with supplied washer and bolt.
- 12 Wipe throttle body clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with clamp.
- 13 Insert the 1st 90 degree bent pipe into the 3" end of the 2.5"-3" coupler, secure with clamp.
- 14 Install the 3"-3" coupler onto the end of the intake tube, secure with clamp.
- 15 Slide intake tube into the heatshield with bracket inside heatshield.
- 16 Insert the 2nd intake tube into the 3" coupler, secure with clamp.
- 17 Slide intake pipe bracket on top of the rubber mounting grommet, secure with supplied washer and nut.
- 18 Insert the supplied hose onto the port on intake pipe and onto the valvecover port.
- 19 Install the 3" Weapon*R Air Filter into the 3" coupler on the intake pipe end, secure with clamp.
- 20 Position air intake pipe for clearance in engine compartment, making sure no parts are touching the vehicle.
- 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 22 Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened.
- 23 Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new
- 24 Air / Fuel Ratio curves to increased air intake to the engine.
- 25 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)
- 26 Perform a final inspection before driving vehicle, Installation is complete.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Recommended Air Filter Cleaning Intervals: 3000 Miles.

NOTE: Please check the contents of this package immediately.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

