



Part# 601-130 SECRET WEAPON TRUCK INTAKE

US Patent# US 7,263,961B2

Application: 1993-98 GRAND CHEROKEE 5.2L / 5.9L V8

Parts List: 1 x 4" Weapon*R Air Filter / 1 x Weapon*R [Air Intake Tube](#) / 1 x 3.5"- 4" Coupler
1 x 3.5" couplers / 1 x 15mm 12" hose / 4 x 4" Hose Clamps / 1 x Heat Shield Kit /
1 x Rubber Mounting Grommet/ 5 x Black air box screws

- 1 Loosen both hose clamps holding the OEM intake tube, remove OEM intake tube.
- 2 Remove the valvecover breather tube from the OEM airbox.
- 3 Unclip the breather hose on side of airbox.
- 4 Unclip the 4 clips holding the airbox top, remove airbox top and air filter.
- 5 Remove the 3 bolts holding the lower half of the airbox, remove the lower airbox.
- 6 Zip tie the breather hose to the power steering fluid line.
- 7 Remove the ambient airduct from fender.
- 8 Install rubber mounting grommet onto the heatshield with exposed threads facing outwards.
- 9 Remove front windshield washer reservoir bolt for later installation.
- 10 Place heatshield in OEM airbox location, slide tab on heatshield under the windshield washer reservoir.
- 11 Assemble heat shield by aligning holes #1 to #1 and so on, secure with screws in kit.
- 12 Install the windshield washer reservoir bolt previously removed on top of the heat shield, bolt to chassis.
- 13 Secure the 2 tabs on bottom of heatshield to chassis with supplied bolts.
- 14 Wipe air intake plenum clean of any grease, install the 3.5" coupler onto plenum, secure with clamp.
- 15 Insert the intake tube into the 3.5" coupler, secure with supplied clamp.
- 16 Install the 3.5"-4" coupler onto the end of the intake tube, secure with clamp.
- 17 Slide intake tube into the heatshield with bracket inside heatshield.
- 18 Slide intake pipe bracket on top of the rubber mounting grommet, secure with supplied washer and nut.
- 19 Insert the OEM valvecover hose onto the port on intake pipe.
- 20 Install the Weapon*R Air Filter into the 4"end of coupler, secure with clamp.
- 21 Position air intake pipe for clearance in engine compartment, making sure no parts are touching the vehicle.
- 22 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 23 Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened.
- 24 Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new
- 25 Air / Fuel Ratio curves to increased air intake to the engine.
- 26 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)
- 27 Perform a final inspection before driving vehicle, Installation is complete.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

NOTE: Recommended Air Filter Cleaning Intervals: 3000 Miles.

Please check the contents of this package immediately.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

