



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part# 601-142 SECRET WEAPON TRUCK INTAKE

US Patent# US 7,263,961B2

Application: 2005-2007 Nissan Froniter / Pathfinder / Xterra

Parts List: 1 x 3" Weapon*R Air Filter / 1 x Weapon*R [Air Intake Tube](#) / 2 x 3" Coupler / 4 x 3" Hose Clamps
1 x Rubber Mounting Grommet / 1 x 15mm x 16" hose / 1 x 4mm silicone

- 1 Disconnect MAF sensor harness
- 2 Loosen the 2 clamps on the OEM intake hose and remove OEM intake hose.
- 3 Remove the hoses connected to the OEM air resonator box.
- 4 Loosen the bolts securing the OEM intake box, remove the complete OEM assembly.
- 6 Loosen the clamp on the throttle body and remove the rest of the OEM intake tube.
- 9 Wipe throttlebody clean of grease or dirt, install 3"-3" coupler onto throttlebody, secure with clamp.
- 10 Insert large WR intake pipe into 3" side of coupler, and clamp down
- 11 Install 3"-3" coupler onto end of intake pipe 3" side to pipe, and clamp down
- 12 Install MAF unit into Adapter welded to the WR intake tube.
- 15 Install the Weapon*R Air Filter onto the 3"-3" coupler, secure with clamp.
- 16 Install WR filter assembly onto end of the WR intake tube and clamp down.
- 18 Use 15mm line and connect to the WR intake pipe and connect to OEM location
- 19 Line up bracket on intake pipe to hole on chassis, install rubber mounting grommet on chassis.
- 20 Slide bracket onto rubber mounting grommet, secure with washer and nut in kit.
- 21 Position air intake pipe for clearance in engine compartment, making sure no parts are touching the vehicle.
- 22 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 23 Inspect engine compartment for loose tools and or loose clamps and bolts to be properly tightened.
- 24 Start engine and let idle for 10 minutes before Revving the engine, to allow the ECU to re-map new
- 25 Air / Fuel Ratio curves to increased air intake to the engine.
- 26 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)
- 27 Perform a final inspection before driving vehicle, Installation is complete.

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Please check the contents of this package immediately.

NOTE: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

