



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

US Patent# US 7,263,961B2

Part # 's **Secret Weapon: 601-150**

Application : **2007 LINCOLN NAVIGATOR 5.4L**

**Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter 4" / 1 x 3.5"- 3.5" Coupler/ 1 X 3.5" -4" Coupler
1 x Intake System Bracket kit / 4 x 3" Clamp**

- 1 Remove bolts securing OEM engine cover and remove engine cover
- 2 Remove the OEM rubber intake tube.
- 3 Unplug mass air sensor, and Remove OEM airbox lid with mass air sensor attached
- 4 Unbolt mass air sensor from top of OEM airbox, put aside.
- 5 Remove rest of OEM airbox
- 6 Wipe the throttlebody clean of any grease, install the 3.5"-3.5" coupler onto throttlebody, secure with OEM clamp.
- 7 Install the WR intake tube into 3.5" side of coupler and clamp down
- 8 Take MAF sensor and bolt into Weapon-R plate adapter on intake tube and screw down
- 9 Install 3.5"-4" coupler onto Secret Weapon air filter, secure with supplied clamp.
- 10 Install filter assembly onto the end of Weapon*R pipe, secure with OEM clamp.
- 11 Install Black intake bracket to the 2 tabs on WR pipe and secure to the truck and bolt down
- 12 Install U-shaped part of intake system bracket under the clamp on air filter.
- 13 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 14 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 15 Secure with washer and nut included in bracket kit.
- 16 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 17 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 18 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

